





Key No.	ART.	Description	QTY.	Key No.	ART.	Description	QTY.
1	1250	Universal Guide	1	46	1272	Anti-Splash Guard 2	1
2	1251	Work Table	1	47	1273	Anti-Splash Guard 1	1
2A	1252	Stop Block 2 of Work Table	1	48	1274	Rotary Spindle of 57	1
2B	1253	Stop Block 1 of Work Table	1	50	1275	Wing Nut	1
2C	1254	Table Lock	1	51	1276	Depth Adjustment Knob	1
3	1255	Extension Table	1	52	1277	Depth Stop Adjustment Knob	1
7	1256	Extension Water Tray	1	53	1278	Motor Unit	1
15D	1257	Stop Spring Plate of Water Tray	1	53A	1279	Carbon Brush Cap	2
15E	1258	Lock Clip of Water Tray	1	53B	1280	Carbon Brush	2
15F	1259	Bolt	2	53C	1281	Main Handle Fix Block	1
15G	1260	Stop Block of Water Tray	1	54	1282	Handle	1
15H	1261	Stop Pin of Watery Tray	1	57	1283	Bevel Cut Adjustment Knob	1
18	1262	Watery Tray	1	69	1284	Nut Wrench	1
18A	1263	Watery Plug	1	70	1285	Allen Wrench	1
24	1264	Inner Flange	1	72	1286	Penstock	1
26	1265	Outer Flange	1	74	1287	Water Pump	1
27	1266	Shaft Nut	1	75	1288	GFCI	1
33	1267	Outer Blade Guard	1	123	1289	Left Foot Cushion	1
36	1268	Laser Beam Guard	1	130	1290	Right Foot Cushion	1
37	1269	Laser Assembly	1	142	1291	Wheel Assembly	2
42	1270	Inner Blade Guard	1	148	1292	Knob	2
43	1271	Rotary Spindle of Blade Guard	1				