



GRABO® Tile Vibration

Assembly Instruction Manual




Introduction

The GRABO Tile Vibration is an innovative attachment engineered for tile installation professionals. It securely locks onto your GRABO tool's four anchor points, offering two powerful vibration modes to efficiently vibrate and settle thinset or mortar beneath tiles. By gripping the tile with your GRABO tool and activating the vibration feature, this attachment ensures even mortar distribution, eliminates trapped air pockets, and optimizes adhesion. This results in perfectly leveled tiles and a seamless finish, significantly reducing manual effort and time. It's ideal for installers working with porcelain, ceramic, stone, or large-format tiles.



Product Components Diagram



Code	Describe	Quantity
A	Power switch	1
B	High/Low adjustment switch	1
C	Battery indicator light	3
D	Battery cover	1
E	Connotation battery	2
F	TYPE-C charging port	1
G	Hand screw assembly	4
H	Base	1
I	Rubber Blocks_R	1
J	Rubber Blocks_L	1
K	Motor cover	1

Specifications

Model	sn75000
Rated voltage	7.2 V
Rated Power	26 W
Battery capacity	2420 mAh
Battery Charging Time	2.5 hours
High Speed Non-Stop Running Time(one fully charged battery)	2 hours
Low Speed Non-Stop Running Time(one fully charged battery)	5 hours
L x W x H	308 x 219 x 55 mm
Net Weight (with battery):	1.1 kg (2.4 lbs)
Working Temperature :	-10~60°C

Runtime indicator status


All three lights remain on	>67%
Two lights are on and the other one is off	33%~67%
One lights is on and the other two are off	10%~33%
One lights is flashing and the other two are off	<10%

Indicator status during charging


One lights is flashing and the other two are off	<10%
One lights is always on, one is flashing, one is off	10%~33%
Two lights are on and the other one is flashing	33%~67%
All three lights remain on	>67%

Assembly


1. Unscrew the 4 locking pins on the Tile Vibration. Ensure the locking pins are pulled outwards prior to unscrewing them from the Tile Vibration.




2. Attach the Tile Vibration to the GRABO tool.



3. Align the 4 locking pins with the metal holes and tighten them securely.




Operation Guide




1. Charge Verification:

Ensure the Tile Vibration is fully charged. When Power Switch A is turned on, if all three LED indicators (or two, or one) illuminate, the tool is ready. If one LED indicator flashes while the others are off, the battery is low and requires charging.




2. Activate GRABO Power:

Activate the Power ON/OFF button C on your GRABO electric suction cup.




3. **Engage GRABO Motor:**

Turn on the Green motor power button D.




4. **Initiate Vibration:**

Once the GRABO electric suction cup has established suction on the tile, activate Power Switch A on the Tile Vibration to begin operation.




5. **Adjust Vibration Speed:**

Press the High/Low Range Switch B to toggle between high and low gear settings.




6. **End Vibration:**

After completing the vibration operation, turn off the Tile Vibration by pressing Power Switch A.




7. **Deactivate GRABO Motor:**

Turn off the Green motor power button D on the GRABO electric suction cup.




8. **Release Suction:**

Press the Red vacuum release button E on the GRABO electric suction cup to release it from the tile.




9. **Disconnect GRABO Power:**

Press the Power ON/OFF button C on the GRABO electric suction cup to turn the power off.



TYPE-C Charge

⚠ Notice: When charging, ensure the Power Switch A is turned off.



Security Statement

 **Warning:** Always read all product usage rules and safety precautions thoroughly before using this product. Retain this manual for future reference. Failure to comply with these guidelines may lead to malfunction and equipment damage.

Questions and Help

If you have any questions about product operation or you need any help, please visit our official website for FAQ guides and troubleshooting.

Official website: <https://www.GRABO.com>

Product Maintenance

After-sales service

If the product you purchased is faulty or damaged, please contact the technicians of the officially authorized repair service station for repair.

 **Notice:** Under no circumstances, except for officially authorized after-sales technical service personnel, anyone may not privately disassemble this product for any purpose. The manufacturer's warranty service will be invalid after the product is privately disassembled.

Waste Recycling

When the product reaches the upper limit of its service life, the product, its accessories and packaging should be recycled in an environmentally friendly manner.

GRABO®

Tile Vibration

Jun. 2025 | Version 1

By GRABO LIMITED - www.GRABO.com